

PASSIVE RESTRAINT SYSTEM INSPECTION

2001 Chevrolet Camaro

GENERAL INFORMATION

Air Bag/SRS Component Inspection & Replacement Tables

General Motors

INTRODUCTION

When a vehicle equipped with passive restraint system has been involved in a collision, certain systems and components must be inspected and or replaced regardless of whether or not the air bag has deployed. Follow the manufacturer's guidelines provided in this article.

WARNING: Accidental air bag deployment is possible. Personal injury may result. Avoid area near steering wheel and instrument panel even if air bags have deployed. Dual-stage air bag modules may be present that could contain an undeployed stage. When disposing of a deployed dual-stage air bag, always treat it as a "live" module. See appropriate AIR BAG RESTRAINT SYSTEM articles in the ACCESSORIES/SAFETY EQUIPMENT section.

GENERAL MOTORS (1988-01)

AIR BAG APPLICATION

APPLICATION

Make/Model	Year	Location	Table
Achieva	1998	D/P	GM-14
	1996-97	D/P	GM-1
	1994-95	DS	GM-2
Alero	1999-01	D/P	GM-14
Allante	1993	DS	GM-5
	1990-92	DS	GM-6
Astro	1997-01	D/P	GM-14
	1996	D/P	GM-1
	1993-95	DS	GM-2
Aurora			
Dual Stage	2001	D/P2, SI	GM-22
Single Stage	2001	D/P, SI	GM-22
	1996-99	D/P	GM-1
	1995	D/P	GM-2
Aztek	2001	D/P, SI	GM-14
Beretta	1993-96	DS	GM-2
	1991-92	DS	GM-5
Blazer	1998-01	D/P	GM-15
	1995-97	DS	GM-2
Bonneville	2001	D/P2, SI	GM-22
	2000	D/P, SI	GM-20
	1997-99	D/P	GM-16
	1994-96	D/P	GM-2
Bonneville SE-SSE	1992-93	DS	GM-2
Bonneville SSE-SSEi	1992-93	D/P	GM-2
Bravada	1998-01	D/P	GM-15
	1996-97	DS	GM-2
C-K Pickup	1994-96	DS	GM-2
	1997-00	D/P	GM-15

	1995-96	DS	GM-2
Camaro	1997-01	D/P	GM-14
	1996	D/P	GM-1
	1993-95	D/P	GM-2
	1990-92	DS	GM-5
Caprice	1995-96	D/P	GM-3
	1994	D/P	GM-2
	1993	DS	GM-2
	1991-92	DS	GM-6
Catera	1997-01	D/P, SI	GM-17
Cavalier	1998-01	D/P	GM-14
	1996-97	D/P	GM-1
	1995	D/P	GM-3
Century	2000-01	D/P, SI	GM-20
	1997-99	D/P	GM-14
	1993-96	DS	GM-2
Chevy Van			
Early Design	1994-96	DS	GM-2
	1997-00	D/P	GM-15
	1995-96	DS	GM-2
New Design	1997-98	D/P	GM-16
Concours	1994-96	D/P	GM-2
Corsica	1993-96	DS	GM-2
	1991-92	DS	GM-5
Corvette	1997-01	D/P	GM-14
	1994-96	D/P	GM-3
	1993	DS	GM-2
	1991-92	DS	GM-5
	1990	DS	GM-7
Custom Cruiser	1991-92	DS	GM-6
Cutlass	1997-99	D/P	GM-14
Cutlass Ciera	1993-96	DS	GM-2
Cutlass Supreme	1997	D/P	GM-14
	1995-96	D/P	GM-4
	1994	DS	GM-2
Delta 88	1988-91	DS	GM-8
DeVille	2000-01	D/P, SI	GM-21
	1994-96	D/P	GM-2
	1993	DS	GM-2
DeVille-Concours			
D'Elegance	1997-99	D/P, SI	GM-18
DeVille-Fleetwood	1992	DS	GM-2
	1989-91	DS	GM-6
Eighty Eight-			
Royal-LS	1997-99	D/P	GM-16
	1994-96	D/P	GM-2
	1993	DS	GM-2
	1992	DS	GM-6
Eldorado	2001	D/P	GM-23
	1997-00	D/P	GM-18
	1993-96	D/P	GM-2
	1990-92	DS	GM-6
Envoy	1998-00	D/P	GM-15
Escalade	2000	D/P	GM-15
Express Van	1997-01	D/P	GM-16
	1996	D/P	GM-1
Firebird	1997-01	D/P	GM-14
	1996	D/P	GM-1
	1993-95	D/P	GM-2
	1990-92	DS	GM-5
Fleetwood Brougham	1993-96	D/P	GM-2
Grand Am	1998-01	D/P	GM-14
	1996-97	D/P	GM-1

	1994-95	DS	GM-2
Grand Prix	1997-01	D/P	GM-14
	1994-96	D/P	GM-4
Impala	2001	D/P2, SI	GM-20
	2000	D/P, SI	GM-20
Impala SS	1995-96	D/P	GM-3
	1994	D/P	GM-2
Intrigue	1998-01	D/P	GM-14
Jimmy	1998-01	D/P	GM-15
	1995-97	DS	GM-2
LeSabre	2001	D/P2, SI	GM-22
	2000	D/P, SI	GM-20
	1997-99	D/P	GM-16
	1994-96	D/P	GM-2
	1993	DS	GM-2
	1992	DS	GM-6
Lumina	1997-00	D/P	GM-14
	1995-96	D/P	GM-4
Lumina APV	1994-96	DS	GM-2
LSS	1997-99	D/P	GM-16
	1996	D/P	GM-2
Malibu	1997-01	D/P	GM-14
Metro	1998-01	D/P	GM-9
	1995-97	D/P	GM-9
	1993	DS	GM-9
	1990-92	DS	GM-11
Montana	1999-01	D/P, SI	GM-14
Monte Carlo	2001	D/P2, SI	GM-20
	2000	D/P, SI	GM-20
	1997-99	D/P	GM-14
	1995-96	D/P	GM-4
Ninety Eight					
Regency	1994-96	D/P	GM-2
	1993	DS	GM-2
	1991-92	DS	GM-6
	1989-90	DS	GM-8
Park Avenue	2000-01	D/P, SI	GM-20
Park Avenue-Ultra	1997-99	D/P	GM-19
	1994-96	D/P	GM-2
	1993	DS	GM-2
	1991-92	DS	GM-6
Prizm	1998-01	D/P, SI	GM-17
	1994-97	D/P	GM-10
	1993	DS	GM-10
Rally-Vandura	1994-96	DS	GM-2
Regency	1997-98	D/P	GM-16
Reatta	1990-91	DS	GM-6
Regal	2000-01	D/P, SI	GM-20
	1997-99	D/P	GM-14
	1995-96	D/P	GM-4
	1994	DS	GM-2
Riviera	1996-99	D/P	GM-1
	1995	D/P	GM-2
	1990-93	DS	GM-6
Roadmaster	1995-96	D/P	GM-3
	1994	D/P	GM-2
	1993	DS	GM-2
	1991-92	DS	GM-6
S10 Pickup	1998-01	DS	GM-15
	1995-97	DS	GM-2
Safari	1997-01	DS	GM-14
	1996	D/P	GM-1
	1993-95	DS	GM-2

Saturn Coupe	1995-99	D/P	GM-12
	1992-94	DS	GM-13
Saturn L-Series	2001	D/P, HI	GM-12
	2000	D/P	GM-12
Saturn S-Series	2001	D/P, HI	GM-12
	2000	D/P	GM-12
Saturn Sedan	1995-99	D/P	GM-12
	1992-94	DS	GM-13
Saturn Wagon	1995-99	D/P	GM-12
	1993-94	DS	GM-13
Savana	1997-01	D/P	GM-16
	1996	D/P	GM-1
Seville	1998-01	D/P, SI	GM-21
	1997	D/P	GM-18
	1993-96	D/P	GM-2
	1990-92	DS	GM-6
Sierra	2001	D/P	GM-20
	1997-00	D/P	GM-15
	1995-96	DS	GM-2
Silhouette	1999-01	D/P, SI	GM-14
	1997-98	D/P	GM-14
	1994-96	DS	GM-2
Silverado	2001	D/P	GM-20
	1999-00	D/P	GM-15
	1995-96	DS	GM-2
Skylark	1998	D/P	GM-14
	1996-97	D/P	GM-1
	1994-95	DS	GM-2
Sonoma	1998-01	D/P	GM-15
	1995-97	DS	GM-2
Sportvan	1994-96	DS	GM-2
Storm	1993	DS	GM-9
	1990-92	DS	GM-11
Suburban	2000-01	D/P, SI	GM-20
	1997-99	D/P	GM-15
	1995-96	DS	GM-2
Sunfire	1998-01	D/P	GM-14
	1996-97	D/P	GM-1
	1995	D/P	GM-3
Tahoe	2000-01	D/P, SI	GM-20
	1997-99	D/P	GM-15
	1995-96	DS	GM-2
Toronado	1990-92	DS	GM-6
Tracker	1998-01	D/P	GM-9
	1996-97	D/P	GM-9
Venture	1999-01	D/P, SI	GM-14
	1997-98	D/P	GM-14
Trans Sport	1997-98	D/P	GM-14
	1994-96	DS	GM-2
Yukon, Yukon XL	2000-01	D/P, SI	GM-20
	1997-99	D/P	GM-15
	1995-96	DS	GM-2

D/P - Driver's & Passenger's Side.

D/P2 - Driver's & Passenger's Side (Dual-Stage).

DS - Driver's Side.

HI - Head Impact.

KI - Knee Impact.

SI - Side Impact.

PS2 - Passenger's Side (Dual-Stage).

INSPECTION PROCEDURES

GM-1

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Forward discriminating sensor (1) * Sensing & Diagnostic Module (SDM) * Sensors in area of accident damage (2) * Instrument panel magnesium beam (3)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Forward discriminating sensor (1) * Instrument panel braces (3) * Instrument panel magnesium beam (4) * Instrument panel steering column reinforcement plate * Knee bolsters & mounting points (4) * Seat belts & mounting points * Sensors in area of accident damage (without deployment) (2) * SIR coil assembly * Steering column (4)
Comments	<p>Any sensor which the Sensing & Diagnostic Module (SDM) indicates as bad must be replaced. If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions. On Chevrolet Express Van & GMC Savana only, check for excessive gaps between dash trim panels following manufacturer's instructions. If gaps are excessive, replace instrument panel magnesium beam.</p>
<p>(1) - Except Camaro, Firebird and 1996-99 Aurora and Rivera. (2) - 1996-98 Aurora and Riviera only. (3) - Chevrolet Express Van and GMC Savana only. (4) - If damaged, also replace instrument panel magnesium beam on Chevrolet Express Van and GMC Savana only.</p>	

GM-2

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Sensors in area of accident damage
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel braces * Instrument panel steering column reinforcement plate * Knee bolster and mounting points * Seat belts & mounting points * Sensors in area of accident damage (without deployment) * SIR coil assembly * Steering column * Steering wheel (1)
Comments	<p>Any sensor which the Diagnostic Energy Reserve Module (DERM) or Sensing & Diagnostic Module (SDM) indicates as bad must be replaced. If any components are damaged or bent, they must</p>

	be replaced. SIR wiring can be repaired following manufacturer's instructions.
(1) - 1995 Aurora, Bonneville, Concours, DeVille, Eighty Eight, Eldorado, Lesabre, Ninety Eight, Park Avenue, Riviera, Seville, and 1995-96 Fleetwood.	

GM-3

Action	Component or System
Replace After Deployment	* Air bag module(s) * All sensors
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	* Instrument panel braces * Instrument panel steering column reinforcement plate * Knee bolster and mounting points * Seat belts & mounting points * Sensors in area of accident damage (without deployment) * SIR coil assembly * Skid plate-skid bar assembly (1) * Steering column * Steering wheel (2)
Comments	Any sensor which the Diagnostic Energy Reserve Module (DERM) indicates as bad must be replaced. If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions.
(1) - 1996 Corvette only. (2) - Cavalier, Corvette and Sunfire only.	

GM-4

Action	Component or System
Replace After Deployment	* Air bag module(s) * Anti-theft module (if equipped)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	* Anti-theft module bracket (if equipped) * Instrument panel braces * Instrument panel steering column reinforcement plate * Knee bolster and mounting points * Seat belts & mounting points * SIR coil assembly * Steering wheel
Comments	Any sensor which the Sensing & Diagnostic Module (SDM) indicates as bad must be replaced. If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions.

GM-5

Action	Component or System
--------	---------------------

Replace After Deployment	<ul style="list-style-type: none"> * Air bag module * Arming sensor * Forward discriminating sensor * Passenger compartment discriminating sensor
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Diagnostic Energy Reserve Module (DERM) * Instrument panel braces * Instrument panel steering column reinforcement plate * Knee bolster & mounting points * Seat belts & mounting points * SIR coil assembly * Steering column * Steering wheel * Wiring harness
Comments	If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions.
<p>(1) - Beretta and Corsica only. (2) - Corvette only.</p>	

GM-6

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module * Dual sensor * Forward discriminating sensor
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel braces * Instrument panel lower trim (1) * Instrument panel steering column reinforcement plate * Knee bolster & mounting points * Seat belts & mounting points * SIR coil assembly * Steering column * Steering wheel * Wiring harness
Comments	If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions.
<p>(1) - LeSabre and Park Avenue only.</p>	

GM-7

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module * Diagnostic Energy Reserve Module (DERM) * Front discrimination sensors * SIR coil assembly
Inspect & If Damaged Replace Component (Even If	<ul style="list-style-type: none"> * Instrument panel braces * Instrument panel steering column reinforcement plate

Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Knee bolster & mounting points * Seat belts & mounting points * SIR coil assembly * Steering column * Steering wheel * Wiring harness
Comments	If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions.

GM-8

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module * Arming sensor * Passenger Compartment Sensor-Diagnostic Module (PCSDM) or SIR control module
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Knee bolster & mounting points * Seat belts & mounting points * SIR coil assembly * Steering column * Wiring harness
Comments	If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions.

GM-9

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Sensing & Diagnostic Module (SDM) (1) * Sensors in area of accident damage (2)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel braces & brackets * Instrument panel steering column reinforcement plate * Knee bolster & mounting points * Seat belts & mounting points * Sensors in area of accident damage (without deployment) (2) * SIR coil assembly * Steering column
Comments	If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions.
(1) - 1996-01 Metro and Tracker only. (2) - 1995-01 Metro only.	

GM-10

Action	Component or System
Replace After	* Air bag module(s)

Deployment	<ul style="list-style-type: none"> * Center sensor assembly * Forward sensors (1)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Center sensor assembly (2) * Forward sensors (1), (2) * Instrument panel steering column reinforcement plate * Knee bolster & mounting points * Seat belts & mounting points * SIR coil assembly * Steering column
Comments	If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions.
<p>(1) - Except 1996-97 models. (2) - Without deployment only.</p>	

GM-11

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module * Arming sensor * Forward discriminating sensor * Passenger compartment discriminating sensor
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel braces * Instrument panel steering column reinforcement plate * Knee bolster & mounting points * Seat belts & mounting points * SIR coil assembly * Steering column
Comments	If any components are damaged or bent, they must be replaced. SIR wiring can be repaired following manufacturer's instructions.

GM-12

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Sensing & Diagnostic Module (SDM) * Cross car beam (2) * Side impact sensor (3)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel mounting attachments * Knee bolster * Seat belts & mounting points * Sensing & Diagnostic Module (SDM) * Side impact sensor (4) * SIR coil assembly * Steering column * Steering column foam energy absorber (1) * Steering wheel
Comments	If any components are damaged or bent, they must be replaced.

- (1) - 1996-01 models only.
- (2) - L-Series models only.
- (3) - On side of impact.
- (4) - Replace sensor if near accident damage area.

GM-13

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module * Sensors in area of accident damage
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Any sensor which DERM indicates as bad * Diagnostic Energy Reserve Module (DERM) * Instrument panel moulding attachments * Knee bolster * Resistor module * Seat belts & mounting points * Sensors in area of accident damage (without deployment) * SIR coil assembly * Steering column * Steering wheel
Comments	If any components are damaged or bent, they must be replaced.

GM-14

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Front sensor (1) * Sensing & Diagnostic Module (SDM) * Sensors in area of accident damage * Theft deterrent module (2) * Side impact inflator module (3) * Side impact sensor (3)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel braces & brackets * Instrument panel cross car beam (4) * Instrument panel knee bolsters * Seat belts & mounting points * Seats & seat mounting points * Steering column * Steering wheel module coil (SIR coil)
Comments	If any components are damaged or bent, they must be replaced.
<ul style="list-style-type: none"> (1) - 2001 Astro and Safari. (2) - Cutlass Supreme, Lumina and Monte Carlo only. (3) - On side of impact. (4) - 2001 models only. 	

GM-15

Action	Component or System

Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Front end discriminating sensor * Sensing & Diagnostic Module (SDM) * Sensors in area of accident damage * Side impact inflator module(s) (1), (2) * Side impact sensor (1), (2)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel braces & brackets * Instrument panel knee bolsters * Seat belts & mounting points * Steering column * Steering wheel module coil (SIR coil) * Sensors in area of accident damage (without deployment)
Comments	If any components are damaged or bent, they must be replaced.
<p>(1) - If equipped. (2) - On side of impact.</p>	

GM-16

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Sensing & Diagnostic Module (SDM) * Instrument panel magnesium beam (1) * Sensors in area of accident damage
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Front end discriminating sensor * Instrument panel braces & brackets * Instrument panel knee bolsters (2) * Instrument panel steering column reinforcement plate (3) * Seat belts & mounting points * Seats & seat mounting points * Sensors in area of accident damage (without deployment) * Steering column (2) * Steering wheel module coil (SIR coil)
Comments	If any components are damaged or bent, they must be replaced. On Chevrolet Express Van & GMC Savana only, check for excessive gaps between dash trim panels following manufacturer's instructions. If gaps are excessive, replace instrument panel magnesium beam.
<p>(1) - Chevrolet Express Van and GMC Savana only. (2) - If damaged, also replace instrument panel magnesium beam on Chevrolet Express Van and GMC Savana only. (3) - Bonneville, Eighty Eight, LeSabre, LSS and Regency only.</p>	

GM-17

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Front end discriminating sensor (1)

	<ul style="list-style-type: none"> * Sensing & Diagnostic Module (SDM) * Seat Belt Pretensioners * Sensors in area of accident damage * Side impact inflator module(s) (2) * Side impact sensor & mounting bracket (2)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Door harness, door seal & seat (2) * Instrument panel braces & brackets * Instrument panel cross car beam (3) * Instrument panel steering column reinforcement plate * Knee bolster & mounting points * Seats & seat mounting points * Seat belts & mounting points * Seat belt pretensioners * Sensors in area of accident damage (without deployment) * Steering column * Steering wheel module coil (SIR coil)
Comments	If any components are damaged or bent, they must be replaced.
<p>(1) - 2001 Prizm. (2) - On side of impact. (3) - On Prizm and 2001 Catera.</p>	

GM-18

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Door assembly (1) * Door trim panel (1) * Instrument panel assembly (2) * Instrument panel upper trim panel * Sensors in area of accident damage * Side impact inflator module(s) (1) * Side Impact Sensing Module (SISM) (1)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Front discriminating sensor * Instrument panel braces * Instrument panel knee bolsters & mounting points * Instrument panel mounting points & brackets * Instrument panel steering column reinforcement plate * Passenger side air bag module mounting points * Side impact inflator module(s) mounting points * Side Impact Sensing Module(s) (SISM) mounting points * Seat belts & mounting points * Sensing & Diagnostic Module (SDM) * Steering column * Steering wheel module coil (SIR coil)
Comments	If any components are damaged or bent, they must be replaced.
<p>(1) - On side of impact. (2) - If passenger-side air bag module mounting points are damaged.</p>	

GM-19

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Instrument panel cross car beam (1) * Sensing & Diagnostic Module (SDM) (2) * Upper instrument panel pad
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel braces * Instrument panel cross car beam * Instrument panel knee bolsters & mounting points * Instrument panel mounting points & brackets * Passenger-side air bag module mounting points * Seat belts & mounting points * Sensing & Diagnostic Module (SDM) * Steering Column * Steering column support bracket * Steering wheel module coil (SIR coil)
Comments	If any components are damaged or bent, they must be replaced.
(1) - If passenger-side air bag module mounting points are damaged. (2) - If in area of accident damage.	

GM-20

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Electronic Frontal Sensor (EFS) (1) * Front end discriminating sensor (1) * Sensing & Diagnostic Module (SDM) * Sensors in area of accident damage * Side impact inflator module(s) (2), (3)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel braces & brackets * Instrument panel cross car beam * Instrument panel steering column reinforcement plate * knee bolsters & mounting points * Seats & seat mounting points * Seat belts & mounting points * Sensors in area of accident damage (without deployment) * Steering Column * Steering wheel module coil (SIR coil)
Comments	If any components are damaged or bent, they must be replaced.
(1) - 2001 models, if equipped. (2) - On side of impact. (3) - If equipped.	

GM-21

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Sensing & Diagnostic Module (SDM) * Seat belt pretensioners * Sensors in area of accident damage * Side impact inflator module(s) (1), (2) * Side impact sensor & mounting bracket (1)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Door harness, door seal & seat * Instrument panel braces * Instrument panel cross car beam * Instrument panel steering column reinforcement plate * knee bolsters & mounting points * Seats & seat mounting points * Seat belts & mounting points * Seat belt pretensioners * Steering Column * Steering wheel module coil (SIR coil)
Comments	If any components are damaged or bent, they must be replaced.
(1) - In side of impact. (2) - Including rear seat air bag on 2000-01 DeVille.	

GM-22

Action	Component or System
Replace After Deployment	<ul style="list-style-type: none"> * Air bag module(s) * Electronic Frontal Sensor (EFS) * Sensing & Diagnostic Module (SDM) * Sensors in area of accident damage * Side impact inflator module(s) (1), (2) * Steering wheel module coil (SIR coil) * Side impact sensor & mounting bracket (1)(2)
Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)	<ul style="list-style-type: none"> * Instrument panel braces & brackets * Instrument panel cross car beam * All mounting points & mounting hardware * knee bolsters & mounting points * Seats & seat mounting points * Seat belts & mounting points * Sensors in area of accident damage (without deployment) * Steering Column * Steering wheel module coil (SIR coil)
Comments	If any components are damaged or bent, they must be replaced.
(1) - On side of impact. (2) - If equipped.	

GM-23

Action	Component or System

<p>Replace After Deployment</p>	<ul style="list-style-type: none"> * Air bag module(s) * Front sensor (front end discriminating sensor) * Sensing & Diagnostic Module (SDM)
<p>Inspect & If Damaged Replace Component (Even If Air Bag Did Not Deploy)</p>	<ul style="list-style-type: none"> * Instrument panel braces & brackets * Instrument panel cross car beam * Instrument panel steering column reinforcement plate * knee bolsters & mounting points * Seats & seat mounting points * Seat belts & mounting points * Sensors in area of accident damage (without deployment) * Steering Column * Steering wheel module coil (SIR coil)
<p>Comments</p>	<p>If any components are damaged or bent, they must be replaced. If mounting points are damaged, repair or replace.</p>